



Oil Spill Equipment

Skimmers • Booms • Fire Boom

Home

AmericanMarine ^{INC.} **Dispersant Equipment • Portable Tanks • Vacuum Systems • Boats • Pumps**

Hablamos Español para su conveniencia. 321-636-5783

Boom Accessories

[Containment Boom](#)

[Specialty Booms](#)

[Boom Reels](#)

[Boom Storage Containers and Trailers](#)

[Boom Accessories](#)

Anchor Systems

Our standard anchor system includes the following components:

- 24 lb. galvanized Danforth anchor
- 8' of 3/8" galvanized chain
- 60' of 5/8" polypropylene rope
- 12" diameter polyethylene hard shell Jim buoy
- 6' of 5/8" polypropylene painter



Systems are routinely custom made to order based on requirements. Anchors of various sizes and types are available, as well as, different lengths and types of rope lines. Stainless steel hardware is available when required.

DOWNLOAD

Adobe PDF Drawing

Anchor Placement

Although each application is different a general rule of thumb for attaching anchors is at 100' intervals. Depending on current and tidal conditions it may be necessary to anchor the barrier on both sides.

Elastec/American Marine: 1309 West Main, Carmi, IL 62821 USA

Call us at (618) 382-2525 Fax (618) 382-3610 E-mail elastec@elastec.com

Updated May 2004. Copyright Elastec/AmericanMarine. All rights reserved.

Custom

Request

Abou

New

Site

Li

F

Dealer

ISO C

Emerg