



## Oil Spill Equipment

Skimmers • Booms • Fire Boom

[Home](#)

**AmericanMarine** <sup>INC.</sup> [Dispersant Equipment](#) • [Portable Tanks](#) • [Vacuum Systems](#) • [Boats](#) • [Pumps](#)

*Hablamos Español para su conveniencia. 321-636-5783*

## Boom Accessories

[Containment Boom](#)

[Specialty Booms](#)

[Boom Reels](#)

[Boom Storage Containers and Trailers](#)

[Boom Accessories](#)

### Tow Bridles

These units are used to tow a boom or barrier through the water such that the boom will be easily maneuvered and not damaged. The bridle connects to the boom end connector and is secured with a toggle pin. A tow line is attached to the tow bridle cable to maneuver the string.

The tow bridle can be equipped with an optional bullet float assembly. This ensures the tow bridle isn't lost if dropped in the water. It also adds buoyancy on the boom while towing.



[Customer Li](#)

[Request Litera](#)

[About Us](#)

[Newsletter](#)

[Site Map](#)

[Links](#)

[FAQ](#)

[Dealer Inquir](#)

[ISO Certified](#)

[Emergency](#)

**Elastec/American Marine:** 1309 West Main, Carmi, IL 62821 USA  
Call us at (618) 382-2525 Fax (618) 382-3610 E-mail [elastec@elastec.com](mailto:elastec@elastec.com)  
Updated May 2004 . Copyright Elastec/AmericanMarine. All rights reserved.